



Install the Battery on bObi Pet

Before bObi Pet can power up, you will need to install her battery. To do this, you will need a Phillips head screwdriver and a new battery, both of which are included inside bObi Pet's box.

Written By: Chelsea



INTRODUCTION

Follow these few steps to easily set up your new bObi Pet's battery or install a new one.

For a video tutorial, go to: <https://www.youtube.com/watch?v=qpfeK7GP...>



TOOLS:

- [Phillips #2 Screwdriver](#) (1)



PARTS:

- [1 bObi Pet battery](#) (1)

Step 1 — Turn bObi Pet Off




- Make sure bObi Pet's power switch is turned OFF.
- Then, flip bObi Pet over onto a flat surface, so the wheels point up.

Step 2 — Open the Battery Compartment



- Remove the two screws holding her battery cover in place.
- Remove the battery cover. Keep the cover and screws close by for the next step.

Step 3 — Plug in the New Battery



- Plug the new battery in at the circuit junction.
- Tuck the wire into the side of the compartment.
- Ensure the wires are not in the way, then, slide the battery straight down.

Step 4 — Replace the Battery Cover



- Replace the battery cover so that it lies flat.
- Reinstall the 2 screws to finish the installation process.

After finishing the battery installation correctly, turn bObi Pet's side power switch to ON and your robotic vacuum should be ready to work.

This document was last generated on 2017-06-22 02:34:26 PM.